

Product Description

Models produced on 3D printers may have smooth surfaces but they are not highly polished. By giving them a mirror finish before casting or mold making the end product will require much less finishing. Thus, the manufacturing consistency and surface quality will be greatly improved.

Polish your models in 3 easy steps!

- 1. Use the **Scotch-Brush** with **Supra Pumice Paste** to remove the fine build lines on the model.
- 2. The **Duratex White Buff** used with **Supra Polishing Creme** produces a very fine and smooth surface.
- ${\bf 3.\ A\ soft\ loose\ Muslin\ Buff\ used\ with\ Platinum\ Pink\ Compound\ leaves\ a\ mirror\ bright\ finish.}$

Product	Description	Item#
Scotch-Brush	Wheel Buff & Brush, 3"	114-5199
Loose White Muslin Buff DURATEX White Buffs	4" x 50 Ply, Thread - 80x80	140-4350
	4" x 1/2", 20 Ply	142-5420
Platinum Pink Compound	For highly reflective surface, 147g.	215-1786
Supra Pumice Paste	Mild cutting action, 80g.	218-2045
Supra Polishing Creme	Ultra High Finishing, 50g	218-2240